Based on the images you uploaded, here's a tutorial for using the software shown in the screenshots:

Software Usage Tutorial

1. Menu and Initial Setup

When you first open the software, the **Menu** bar is displayed at the top, which provides several options for managing the device and adjusting settings.

Connection Settings:

Connection Address: Use the DIP switch to set the address for the device.

Baud Rate: Set the communication speed (default is 115200).

Connection Port: Select the communication port (e.g., COM4).

To start the software and set up your device, you need to choose the **connection address**, the **baud rate**, and the **communication port** that your device uses. Once set, click **Update Serial Connection** to establish the connection.

2. Language Settings

If you wish to change the interface language, go to the **Menu** and select **Language**. Options include English, Spanish, French, Chinese, Japanese, and others.

3. Device Configuration

After setting the connection, you can configure the device by navigating to **Device Configuration**. Here, you can adjust various device-specific settings such as:

- **Sampling Rate**: Adjust how frequently data is read from the device.
- **Read Rate**: Set the frequency at which the system reads data (e.g., 10 Hz).
- **Zero Calibration**: Adjust settings for zero-point calibration to ensure accurate readings.

Press **Update Read Rate** to apply changes.

4. Data Graph

蚌埠知重仪器销售有限公司BENGBUZZYQ

You can view the real-time data graph of the device's readings in the **Data Graph** section. This graph shows the data from all channels, such as the current weight in grams. You can adjust the scale and track changes over time.

5. Weight and Channel Readings

The **Current Weight** section displays the live data from your connected channels. Each channel has an individual box displaying peak, value, and valley readings:

Peak: Maximum value recorded.

Valley: Minimum value recorded.

Value: The current reading.

You can select which channels to display by ticking the checkboxes next to the channels.

6. Calibration and Command Window

For calibration:

Choose **Zero Calibration** or **Multi-point calibration** depending on your device needs.

Adjust settings such as **Dynamic Zero Tracking** and **Creep Tracking Range**

The **Command Window** at the bottom shows communication between the device and the software, allowing you to manually read and write data to the device using the provided commands.

7. Import/Export Data

To manage data logs, you can:

Import: Load existing data.

Export: Export data to Excel.

Clear: Delete current logs.

This is especially useful for tracking historical data or sharing the readings.

8. Full-Screen Mode

For better visualization, you can click **Full Screen** to expand the data graph and see the readings more clearly.

9. Tare and Reset

蚌埠知重仪器销售有限公司BENGBUZZYQ

If you need to reset the readings, you can click the **Tare** button for each channel to zero out the weight measurement.

This covers the basic features and usage steps of the software. Adjust settings as per your device's requirements and monitor the data through real-time graphs for accurate analysis.

蚌埠知重仪器销售有限公司BENGBUZZYQ